



harmony[®]

**SLIDETRAX DASHBOARD
INSTALLATION INSTRUCTIONS**

Slide Trax Dashboard Instructions

Parts Include:

- (1) Starlight Deck
- (2) Upright
- (4) 1/4x20 x 1 5/8" Philips trusshead
- (4) 1/4x20 Locknut
- (8) Washer
- (4) 1/4x20x 1 1/8" socket-head
- (4) Brass Plates



1) Attach the two uprights to the underside of the deck with the four 1/4x20x1 5/8" Philips trussheads, four stainless washers and the four 1/4x20 lock nuts. Start by sliding the washers, smooth-side down, onto the trussheads. Then run the trussheads through the slots on each end of the deck. Slide the uprights onto the trussheads and secure with the locknuts. Do not over tighten; the uprights should slide back and forth in the slots on the deck. End of bolts should be flush with the outside edge of the nuts, locking it into the plastic in the locknut.

2) Run the 1/4x20x1 1/8" socketheads through the four remaining washers and the open holes on the bases of the uprights. Screw on the brass plates, leaving enough space between the bottom of the upright and the top side of the brass plates to slide the brass plate into the slot on the Slide Trax System so that it stretches from one side of your kayak to the other.

3) Slide the unit onto the tracks.

4) Assuming the boat's footbraces are in the correct position (if not sit in your boat and adjust the foot braces), slide the unit down the track until it rests just in front of the foot pegs. **Do not position the unit over your ankles or legs; this could present an entrapment hazard!**

5) Tighten the allen heads to secure the unit.

6) To remove unit simply loosen hex heads and slide unit off the tracks.

7) The holes drilled across the dashboard are spaced to align to the mounting holes in the ubiquitous Scotty #241 base mount for rod holders. Installation is fast and easy with appropriate hardware.

8) The Starlite material is easily drilled for custom mounting. Use care in identifying mounting hardware so that the hardware does not extend further than necessary from bottom of board to reduce any threat of being cut by exposed ends of screws.

For additional instructions or suggestions for mounting accessories see our web site madfroggear.com