



## THRIVE BAITWELL CONSUMER INSTRUCTIONS

The Wilderness Systems Thrive Baitwell is designed to keep your bait alive and attractive by circulating the natural water of your bait through the well. The pump system is self-priming and includes a backflow valve to prevent water draining back through pump when pump is turned off.

- Capacity – 26 liters total; drain levels are lower
  - Battery – 15 Amp
  - Output – 12 volt for pump; 5v for USB outlet
  - Flow rate – 3 liters per minute
  - Power draw – 18 watts
- Included:
- Baitwell with internal pump and battery system
  - Mesh bag
  - Intake hose
  - 2 drain pipes
  - USB charging cord

### Installation:

- Install the intake hose onto the elbow joint located at the bottom front of the Thrive Baitwell. Run hose through your choice of scupper into water.
- Install the drain pipe into the opening located at the bottom of the baitwell. To allow different water level options within your Thrive Baitwell, there are two different sizes of drain pipes available – full size and half size. Gently push and twist your choice of drain pipe into the receptacle until fully seated.
- Install the mesh bag on the top rim of the Thrive Baitwell while it is in the open position.
- Tie the baitwell down securely to your kayak by using the tie down points found on the Thrive Baitwell.

### Operation:

- Fully charge the battery before use:
- Attach USB cable to the input port on the Baitwell and any USB charging device.
- The lights will flash while charging and will turn solid when fully charged.
- Press the power button once to check the charge status. Lights will illuminate for 30 seconds and will show power range from 0-100%.
- The motor features two modes of operation – continuous and intermittent
- Press the button 2 times to turn the motor on. It will automatically run in the continuous mode. The lights will stay on continuously while in this mode.
- To switch to intermittent mode, press the button for 3 seconds. In this mode, the motor will run for 5 minutes and then pause temporarily for 15 minutes. The lights will flash once per second while in this mode.
- To switch back to continuous mode, press the button for 3 seconds.
- Both Options – press the power button twice to turn the motor off.
- The pump is self-priming and will draw water into the baitwell even when it's empty. To accelerate the fill process, it is helpful to manually add water to the baitwell.
- When battery power reaches 25%, lights will flash twice per second.
- The Thrive Baitwell is also a power bank that can be used for charging small USB devices such as phones and cameras.
- Remove the cap and install a standard USB cable to do so.
- The Wilderness Systems Solar Panel is available for purchase and can be used to top off the Thrive Baitwell's battery. To charge from the Solar Panels, install the USB cable from the Solar Panels to the power input jack of the Baitwell.

### Care & Maintenance:

- Pump fresh cool water through the system after each use to purge debris and salt particles. This is especially important after use in salt water.
- Store in cool dry place.
- If stored for long periods of time, top off battery every 2-3 months to avoid battery going flat.

**NOTE:** The Baitwell's battery is splash resistant but not waterproof. DO NOT SUBMERGE!