

HELIX PD HANGER REWORK INSTRUCTIONS

Tools Needed:

#1 Philips Head Screw Driver
1/8" Drill Bit
Needle Nose Pliers
Safety Glasses

Kit Includes:

(4) 4/40 Nylon Lock Nuts
(4) 4-40X11/16 Flat Head Screws
Latch Hangers
Latch Cams

Notes:

Please wear safety glasses while working on your Helix PD Pedal Drive unit.
For a video tutorial on this process please visit WildernessSystems.com.


If you need additional assistance please contact Customer Service at 888-525-2925 and reference Part#30000064.

Step 1: If hanger is still attached, remove hanger with screwdriver.


Step 2: With an 1/8" drill bit, drill through screw hole regardless if the brass inserts are still in the drive unit or not.




Step 3: Clean any debris from hanger location. Insert screws through new hanger and through block.



Step 4: Hold nut with finger to start.



Step 5: Once you have it started use needle nose pliers to tighten.



Step 6: Repeat steps for other side if needed.